

MOC FUEL ADAPTERS

Master List

2/5/07



72001
FORD 3/8 Supply



72002
FORD 1/2 Supply



72003
12 mm Banjo



72004
8 mm Cold start



72005
12 mm Cold start



72006
1/4 X 5/16 barb TBI



72007
7/16-20 X 5/16 barb



72008
5/16 open supply



72009
5/16 Plug



72010
GM cold start



72011
3/8 GM TBI



72012
10 mm cold start



72013
12 mm L- Jetronic



72014
14 mm L- Jetronic



72017
15 mm Mitsubishi



72018
12 mm Banjo Bolt



72019
90 Degree Schrader



72021
1/4 Ford Return Plug



72022
GM Return Plug



72023
5/16 Return Plug



72024
3/8 Q.D. Return Plug



72025
1/2 Q.D. Return Plug



72026
12 mm Return Plug



72027
14 mm Return Plug



72028
8 mm Return Plug



72029
12 mm Cap Nut



72031
G. M. TBI



72034
1/4 Duckbill QD



72035
5/16 X 1/4 Return Loop



2036
14 MM X 5/16 Barb



72037
3/8 Ford Disconnect Tool



72038
1/2 Ford Disconnect Tool



72039
5/16 G.M. Release



72040
3/8 G.M. Release



72041
Clamp Small



72048
5/16 BMW



72050
5/16 X 5/16 Barb Loop



72051
3/8 Supply



72054
12 mm Double Banjo



72055
12 mm Copper Washer



72057
Toyota Tacoma Truck



72058
12 mm X 14 mm Banjo



72099
Ford Schrader Q.D.



72100
12mm Cold Start Toyota



72101
5/16 Quick Disconnect



72102
3/8 Quick Disconnect



72103
Maxima 2000-up Male



72106
Ford Focus 2003-UP



74466
45 Degree Schrader



72501
12 mm Banjo long hose



73031
1/4 Male Quick Disc



74275
3/8 Female Q.D



74276
5/16 Female QD



73033
19 mm Mitsubishi



74234
Maxima 2000-up Female



74239
3/8 Threaded TBI



72107
GM Schrader Stra.



72108
Cap, Fuel 7/16



94054
Pinch Pliers

Acura / Honda			Chrysler, Kit	
73000	Acura / Honda Kit		73005	Chrysler, Dodge Plym
72003	12mm Hose, Banjo		72003	12mm Banjo Threaded
72023	5/16" Return Plug		72007	7/16-20 X5/16 BARB
72029	12 mm Cap Nut		72008	5/16" Supply Adapter
72034	1/4 Duckbill Adapter QD		72010	GM Cold Start Adapter
72041	Hose Clamp		72017	16mm Mitsubishi Adapter
72054	Bolt, 12mm Dale Banjo		72018	12mm Banjo Bolt
72055	Washer, 12mm Copper		72019	90Degree Schrader GM
72058	12mm X14mm Banjo		72023	5/16" Return Plug
72101	Adaptor 5/16 Male QD		72026	12mm Return Plug
72102	Adaptor 3/8 Male QD		72034	1/4 Duckbill QD Female
72106	Ford Focus 2003		72035	5/16" x 1/4" Barb Loop
72108	Cap,Fuel/Gasket 7/16-20		72101	5/16 Quick Disconnect
72501	Long Hose w/Banjo		72102	Adaptor 3/8 Male QD
73031	1/4 male Quick Dis.		72103	10mm Mitsubishi Adapter
74275	Adaptor Female 3/8 QD		72107	Adaptor GM Schrader
74276	Adaptor Female 5/16 QD		73031	1/4 Male Quick Dis.
			74275	Adaptor Female 3/8 QD
			74276	Adaptor Female 5/16 QD
Alfa Romeo Kit				
73002	Alfa Romero		Daihatsu Kit	
72008	5/16" Supply Adapter		73006	Daihatsu Kit
			72004	8mm Cold Start Adapter
Audi Kit			72012	10mm Cold Start Adapter
73003	Audi Kit		72023	5/16" Return Plug
72003	12mm Hose, Banjo			
72005	12mm Cold Start Adapter		Fiat Kit	
72014	14mm L-Jetronic Threaded		73007	Fiat Kit
72018	12mm Banjo Bolt		72008	5/16" Supply Adapter
72026	12mm Return Plug		72023	5/16" Return Plug
72027	14mm Return Plug			
			Ford, Kit	
BMW Kit			73008	Ford, Lincoln Mercury,
73004	BMW Kit		72001	3/8" Quick Supply
72005	12mm Cold Start Adapter		72002	1/2" Quick Supply
72008	5/16" Supply Adapter		72008	5/16" Supply Adapter
72026	12mm Return Plug		72021	Ford Return Plug
72099	Adapter Portrait, Ford Q D		72023	5/16" Return Plug
72048	Adaptor 5/16 BMW		72024	3/8" Quick Return
			72025	1/2" Quick Return
			72034	1/4" Duckbill Adapter
			72037	3/8" Ford Disconnect
			72038	1/2" Ford Disconnect
			72041	Hose Clamp Small
			72099	Adapter Portrait, Ford QD
			72106	Ford Focus 2003
			72108	Cap, Fuel / Gasket 7/16
			74275	Adaptor Female 3/8 QD
			74276	Adaptor Female 5/16 QD

General Motors			Kia	
73010	General Motors Kit		73034	KIA KIT
72005	12mm Cold Start Adapter		72099	Schrader quick dis.
72008	5/16" Supply Adapter		72023	5/15 return plug
72009	5/16" Inverted Plug		72101	5/16 Quick Disconnect
72010	GM Cold Start Adapters		74276	Adaptor Female 5/16 QD
72011	GM TBI Adapter			
72021	Ford Return Plug		Mazda Kit	
72022	GM Return Plug		73015	Mazda Kit
72023	5/16" Return Plug		72008	5/16" Supply Adapter
72031	GM TBI Special Adapter		72023	5/16" Return Plug
72039	5/16" GM Release Tool		72035	5/16" x 1/4" Barb Loop
72040	3/8" GM Release Tool		72099	Portrait, Ford Q D
72041	Hose Clamp Small		72041	Hose Clamp Small
72102	3/8 Male Quick Disc			
72107	Adaptor GM Schrader		Mercedes Kit	
74239	Adapter at Filter 3/8 TBI		73016	Mercedes Kit
74275	Fuel, Female 3/8 QD		72005	12mm Cold Start Adapter
72101	5/16 Quick Disconnect		72014	14mm L-Jetronic
74276	Adaptor Female 5/16 QD		72026	12mm Return Plug
			72107	Adaptor GM Schrader
Hyundai Kit				
73011	Hyundai Kit		Mitsubishi Kit	
72003	12mm Banjo Threaded		73017	Mitsubishi Kit
72017	16mm Mitsubishi Adapter		72017	16mm Mitsubishi Adapter
72103	10mm Mitsubishi male		72019	90 Degree Adapter
			72103	10mm Mitsubishi male
Isuzu Kit			73033	19 MM Mitsubishi Male
73012	Isuzu Kit		74234	Maxima 2000 -up Female
72008	5/16" Supply Adapter			
72023	5/16" Return Plug		Nissan Kit	
			73018	Nissan Kit
Jaguar Kit			72008	5/16" Supply Adapter
73013	Jaguar Kit		72023	5/16" Return Plug
72008	5/16" Supply Adapter		72035	5/16" x 1/4" Barb Loop
72014	14mm L-Jetronic Threaded		72041	Hose Clamp
72023	5/16" Return Plug		72050	5/16" x 5/16" Barb
72027	14mm Return Plug		72103	Maxima (2000 -up) male
			74234	Maxima 2003 female
Jeep, Kit				
73014	Jeep, Eagle, Renault		Peugeot Kit	
72006	AMC TBI Adapter		73019	Peugeot Kit
72008	5/16" Supply Adapter		72003	12mm Banjo Threaded
72009	5/16" Inverted Plug			
72022	GM Return Plug			
72023	5/16" Return Plug			
72041	Hose Clamp Small			
72107	Adaptor GM Schrader			

Porsche Kit			Toyota, Lexus Kit		
73020	Porsche Kit		73026	Toyota, Lexus Kit	
72003	12mm Banjo Threaded		72003	12mm Banjo Threaded	
72008	5/16" Supply Adapter		72004	8mm Cold Start Adapter	
72013	12mm L-Jetronic Threaded		72005	12mm Cold Start Adapter	
72026	12mm Return Plug		72010	GM Cold Start Adapter	
72035	5/16" x 1/4" Barb Loop		72012	10mm Cold Start Adapter	
72041	Hose Clamp Small		72029	12mm Cap Nut	
			72041	Hose Clamp Small	
			72055	Washer, 12mm Copper	
Saab Kit			72057	Toyota/Tacoma Truck	
73021	Saab Kit		72100	Cold start Camay	
72003	12mm Banjo Threaded		72101	Corolla	
72026	12mm Return Plug		74276	Adaptor Female 5/16 QD	
Saturn					
73022	Saturn Kit		Toyota Special		
72008	5/16" Supply Adapter		73027	Toyota Special Kit	
72009	5/16" Inverted Plug		72004	8mm Cold Start Adapter	
72011	GM TBI Adapter-Early		72010	GM Cold Start Adapter	
72022	GM Return Plug		72012	10mm Cold Start Adapter	
72023	5/16" Return Plug				
72031	GM TBI Special Adapter				
72039	5/16" GM Release Tool		Volvo Kit	73028	
72040	3/8" GM Release Tool		73028		
72041	Hose Clamp Small		72003	12mm Banjo Threaded	
72107	Adaptor GM Schrader		72005	12mm Cold Start Adapter	
			72014	14mm L-Jetronic	
			72023	5/16" Return Plug	
			72026	12mm Return Plug	
Sterling Kit			72036	14mm x 5/16" Barb	
73023	Sterling Kit		72099	Portrait, Ford Q D	
72003	12mm Banjo Threaded		72041	Hose Clamp Small	
Subaru Kit					
73024	Subaru Kit		Volkswagen		
72008	5/16" Supply Adapter		73029	Volkswagen Kit	
72023	5/16" Return Plug		72003	12mm Banjo Threaded	
72035	5/16" x 1/4 Barb Loop		72005	12mm Cold Start Adapter	
72041	Hose Clamp Small		72012	10mm Cold Start Adapter	
			72013	12mm L-Jetronic	
			72014	14mm L-Jetronic	
Suzuki Kit			72023	5/16" Return Plug	
73025	Suzuki Kit		72026	12mm Return Plug	
72008	5/16" Supply Adapter		72035	5/4 x 5/16 Hose Loop	
72023	5/16" Return Plug		72036	14mm x 5/16" Barb	
72035	5/16" x 1/4 Barb Loop		72041	Hose Clamp Small	
72041	Hose Clamp Small		72050	5/16" x 5/16" Barb	
			72051	3/8" Supply Adapter	
			72055	Washer, 12mm Copper	